







INSTRUCTION FOR USE

PreMoist Swab Kits

All samples should be kept cool until testing is performed.

| | |
|---|--|
| <p>STEP 1</p> <p>Identify the site to be sampled.</p>  | <p>STEP 2</p> <p>Hold the swab with both hands and pull the swab cap away from the tube, breaking the security seal in the process.</p>  |
| <p>STEP 3</p> <p>Remove swab using the cap as a holder. Do not touch the swab tip or shaft and make sure that it does not touch any surface before sampling.</p>  | <p>STEP 4</p> <p>Keep the open transport tube with solution within reach, sample designated area using a template if possible. If the area permits, swab in 3 planes (horizontal, vertical and diagonal) whilst rotating.</p>  |
| <p>STEP 5</p> <p>When sampling is completed insert swab into the tube and push cap on tightly.</p>  | <p>STEP 6</p> <p>Write sample details on label, store in a cool (4°C -8°C), dry area and send to the laboratory within 24 hours for analysis.</p>  |

Have you considered?

Sterile Sampling Template - TS/15-T



Technical Service
Consultants Ltd

www.tscswabs.co.uk
Tel: +44 (0)1706 620600

IFU_PreMoist_Swab_V1 –
21/03/2014